## rellis-exploration

February 21, 2022

## 1 RELLIS-3D Dataset Exploration

Exploring the RELLIS-3D dataset for VIPR project.

Notes:

- Rellis image dataset contains 3 image datasets which are derived from 5 different videos (mix of jpg and png files)
  - RGB images, label color images, label id images
  - RGB images contain every frame while the label color and id are every EVEN frame
  - Label color are the segemented ground truth images
  - Label ID a grayscale image that maps the pixel value to the class label (sky, tree, mud etc.)
- In this notebook I extracted each folder seperately and renamed them so there would be 3 separate folders
- If extracting all 3 folders (rgb, label color, and label id) in linux they will all be put in the Rellis-3D folder

#### 1.1 Import libraries and define dataset file paths

```
[1]: from IPython.display import display import os from pathlib import Path from collections import Counter import numpy as np import matplotlib.pyplot as plt import matplotlib.image as mpimg import matplotlib.patches as mpatches
```

```
[2]: ROOT_DIR = os.getcwd() # notebook directory

RGB_DIR = os.path.join(ROOT_DIR,"../../datasets/rellis/Rellis-3D-rgb")

LABEL_COLOR_DIR = os.path.join(ROOT_DIR,"../../datasets/rellis/

→Rellis-3D-label-color")

LABEL_ID_DIR = os.path.join(ROOT_DIR,"../../datasets/rellis/Rellis-3D-label-id")

LIDAR_DIR = os.path.join(ROOT_DIR, "../../datasets/rellis/

→Rellis_3D_os1_cloud_node_color_ply/Rellis-3D") # LIDAR dataset
```

Check a file path to make sure we are looking in the correct folder

```
[3]: print(os.listdir(RGB_DIR)) # check to see if in correct directory print(os.listdir(LIDAR_DIR)) # check to see if in correct directory
```

```
['00002', '00001', '00003', '00004', '00000']
['00002', '00001', '00004', '00003', '00000']
```

### 1.2 Load Images

Displaying the size of each folder about and collect the image file paths to load the images.

```
[4]: def folder_info(directory):
         """Find the number of frames per video in a folder (rgb, label color, label_{\sqcup}
         and return the file path for each frame. Also return the video id and number \sqcup
      ⇔ frames for plotting
         .....
         subdirs = []
         num_files = []
         frame_file_paths = []
         for subdir, dirs, files in os.walk(directory):
             dir_name = subdir.split(os.path.sep)[-1]
             for file in sorted(files):
                  image_path = os.path.join(subdir, file)
                  if 'ipynb_checkpoints' not in image_path and Path(image_path).stem_
      →not in frame_file_paths:
                      frame_file_paths.append(image_path)
             if dir_name != '.ipynb_checkpoints'and '.ipynb_checkpoints' not in files:
                  subdirs.append(subdir.split(os.path.sep)[-1])
                  num_files.append(len(files))
         \#print("""\{0:<21\} - Video: \{1\} has \{2:<5\} frames, Video: \{3\} has \{4:<5\}_{\sqcup}
      \rightarrow frames, Video: {5} has {6:<5} frames,
         #
                                Video: {7} has {8:<5} frames, Video: {9} has {10:<5}
      →frames"""
                               .format(subdirs[0], subdirs[1], num_files[2],
      \rightarrow subdirs[3], num_files[4],
                                subdirs[5], num_files[6], subdirs[7], num_files[8],__
      \rightarrow subdirs[9], num_files[10]))
         # Create list of video # and its number of frames, next sort the frames list _{f \sqcup}
      →based on the video # then sort the video # list
         videos = [subdirs[1], subdirs[3], subdirs[5], subdirs[7], subdirs[9]]
         num_frames = [num_files[2], num_files[4], num_files[6], num_files[8],
      →num_files[10]]
         num_frames = [num_frames for _, num_frames in sorted(zip(videos,_
      →num_frames))] # sorting based on videos list
```


```
videos = sorted(videos)
return frame_file_paths, videos, num_frames
```

```
[5]: def bar_subplots(X, y, row_num = 1, col_num = 3, titles = ['RGB', 'Label Color', __
      →'Label ID']):
         """Create multiple bar plots using subplots sharing the same y axis and \sqcup
      ⇔contain bar labels"""
         # Define plot dimensions and size
         rows = row_num
         cols = col_num
         plot_size = 5
         # Create subplot and loop through the seperate axes
         fig, axes = plt.subplots(rows, cols, figsize=(plot_size * cols, plot_size *_
      →rows), sharey=True)
         y_limit = np.amax(X) # get max value in 2D array
         for i in range(rows * cols):
             axes[i].bar(y, X[i])
             axes[i].set_xticks(y) # Specify labels to suppress xticklabel warning
             axes[i].set_xticklabels(y, rotation=30)
             axes[i].set_title(titles[i])
             axes[i].set_ylim([0, y_limit + 1000]) # increase y-axis to max value +_
      →1000
             rects = axes[i].patches
             # Label bars with exact value
             labels = [f"label{i}" for i in range(len(rects))]
             for rect, label in zip(rects, X[i]):
                 height = rect.get_height()
                 axes[i].text(
                     rect.get_x() + rect.get_width() / 2, height + 5, label,_
      ⇔ha="center", va="bottom"
                 )
         fig.text(0.5, -0.01, 'Video Number', ha='center')
         fig.text(-0.01, 0.5, 'Number of Frames', va='center', rotation='vertical')
         fig.suptitle('Number of Frames Per Video', y=1.05)
         fig.tight_layout()
```

## 1.2.1 Number of files per video

```
[6]: # File paths to each type of frame and number of frames
all_num_frames = []
rgb_frames = []
label_color_frames = []
label_id_frames = []
```

```
rgb_frames, video_number, num_frames = folder_info(RGB_DIR)
all_num_frames.append(num_frames)
label_color_frames, video_number, num_frames = folder_info(LABEL_COLOR_DIR)
all_num_frames.append(num_frames)
label_id_frames, video_number, num_frames = folder_info(LABEL_ID_DIR)
all_num_frames.append(num_frames)
bar_subplots(all_num_frames, video_number)
```




Remove duplicates and frames that do not have a ground truth. Because there are only labels for the even frames, this will probably remove most odd rgb frames. Duplicate names that have a different file extension will not be deleted and must be handled manually, these files will be printed out below.

```
id_dupes = [k for k in id_dupe_count if id_dupe_count[k] >= 2]
if len(rgb_dupes) > 0:
    print("Warning: The RGB images contain the following duplicate images, __
 →manually delete these: {}".format(rgb_dupes))
if len(color_dupes) > 0:
    print("Warning: The c images contain the following duplicate images, ...
 →manually delete these: {}".format(color_dupes))
if len(id_dupes) > 0:
    print("Warning: The color id images contain the following duplicate images, ⊔
 →manually delete these: \n{}".format(id_dupes))
# Remove frames from image list if they are not shared between all 3 image lists
for frame_file in rgb_frames[:]: # iterating through copy of the list
    frame_file_short = Path(frame_file).stem
    if frame_file_short not in common_frames:
        rgb_frames.remove(frame_file)
for frame_file in label_color_frames[:]:
    frame_file_short = Path(frame_file).stem
    if frame_file_short not in common_frames:
        label_color_frames.remove(frame_file)
for frame_file in label_id_frames[:]:
    frame_file_short = Path(frame_file).stem
    if frame_file_short not in common_frames:
        label_id_frames.remove(frame_file)
print("{} RGB frames".format(len(rgb_frames)))
print("{} Color frames".format(len(label_color_frames)))
print("{} ID frames".format(len(label_id_frames)))
# Sort final lists - they should already be sorted but for some reason they.
 \rightarrow aren't
                     (I think its because the directories on returning in_
 \rightarrow different orders)
rgb_frames = sorted(rgb_frames)
label_color_frames = sorted(label_color_frames)
label_id_frames = sorted(label_id_frames)
6234 RGB frames
6234 Color frames
6234 ID frames
```

#### 1.2.2 Display random images from the dataset - RGB, Color, ID

```
[8]: rows = 3
cols = 3
plot_size = 4
```


```
image_type_iterable = [rgb_frames, label_color_frames, label_id_frames]
indices = np.random.choice(np.arange(len(rgb_frames)), rows)
indices = np.repeat(indices, cols) # repeat indices to align for 3 images
plt.figure(figsize=(plot_size * cols, plot_size * rows))
for i in range(rows * cols):
    index = indices[i]
    wrap_index = i % len(image_type_iterable) # index used to wrap around the_
 \rightarrow list
    image_data = mpimg.imread(image_type_iterable[wrap_index][index])
    #image_data2 = mpimg.imread(label_color_frames[index])
    #image_data3 = mpimg.imread(label_id_frames[0])
    ax = plt.subplot(rows, cols, i + 1)
    plt.imshow(image_data, cmap="gray")
    plt.title(Path(image_type_iterable[wrap_index][index]).stem)
    ax.get_xaxis().set_visible(False)
    ax.get_yaxis().set_visible(False)
plt.subplots_adjust(hspace=-0.5)
```



#### 1.2.3 Display segemented image with classes

```
[9]: # Taken from rellis github
     color_palette = {
         0: {"color": [0, 0, 0], "name": "void"},
         1: {"color": [108, 64, 20], "name": "dirt"},
         3: {"color": [0, 102, 0], "name": "grass"},
         4: {"color": [0, 255, 0], "name": "tree"},
         5: {"color": [0, 153, 153], "name": "pole"},
         6: {"color": [0, 128, 255], "name": "water"},
         7: {"color": [0, 0, 255], "name": "sky"},
         8: {"color": [255, 255, 0], "name": "vehicle"},
         9: {"color": [255, 0, 127], "name": "object"},
         10: {"color": [64, 64, 64], "name": "asphalt"},
         12: {"color": [255, 0, 0], "name": "building"},
         15: {"color": [102, 0, 0], "name": "log"},
         17: {"color": [204, 153, 255], "name": "person"},
         18: {"color": [102, 0, 204], "name": "fence"},
         19: {"color": [255, 153, 204], "name": "bush"},
         23: {"color": [170, 170, 170], "name": "concrete"},
         27: {"color": [41, 121, 255], "name": "barrier"},
         31: {"color": [134, 255, 239], "name": "puddle"},
         33: {"color": [99, 66, 34], "name": "mud"},
         34: {"color": [110, 22, 138], "name": "rubble"}
     }
         """Plot random label color image with class labels"""
         index = np.random.choice(len(label_array))
         image = mpimg.imread(label_array[index])
         # Convert color palette to list of colors and labels
         colors = [ [value['color'][0] / 255, value['color'][1] / 255,
```

[11]: plot\_sample\_image(label\_color\_frames)



## 1.3 Attempting to load all images

```
[12]: def load_images_by_path(frame_path):
    image_list = []
    i = 0
    for image in rgb_frames:
        print(i)
        i += 1
        image_list.append(mpimg.imread(image))

# Jupyter crashes after loading anywhere from 2000-6000 images
#loaded_rgb_images = load_images_by_path()
```

## 2 LIDAR

Exploring the LiDAR data in this section.

There doesn't seem to be a good solution for veiwing lidar data on the palmetto.

```
[13]: def lidar_info(directory):

"""Find the number of frames per video in a folder (rgb, label color, label

→id)

and return the file path for each frame. Also return the video id and number

→frames for plotting

"""

subdirs = []

num_files = []

frame_file_paths = []
```

```
for subdir, dirs, files in os.walk(directory):
              dir_name = subdir.split(os.path.sep)[-1]
              for file in sorted(files):
                   image_path = os.path.join(subdir, file)
                   if 'ipynb_checkpoints' not in image_path and Path(image_path).stemu
       →not in frame_file_paths:
                       frame_file_paths.append(image_path)
              if dir_name != '.ipynb_checkpoints'and '.ipynb_checkpoints' not in files:
                   subdirs.append(subdir.split(os.path.sep)[-1])
                   num_files.append(len(files))
          \#print("""\{0:<21\} - Video: \{1\} has \{2:<5\} frames, Video: \{3\} has \{4:<5\}_{\sqcup}
       \rightarrow frames, Video: {5} has {6:<5} frames,
                                 Video: {7} has {8:<5} frames, Video: {9} has {10:<5}
       →frames"""
          #
                                 .format(subdirs[0], subdirs[1], num_files[2], ___
       \rightarrow subdirs[3], num_files[4],
                                 subdirs[5], num_files[6], subdirs[7], num_files[8],__
       \rightarrow subdirs[9], num_files[10]))
          # Create list of video # and its number of frames, next sort the frames list_{\sf L}
       \hookrightarrowbased on the video # then sort the video # list
          videos = [subdirs[1], subdirs[3], subdirs[5], subdirs[7], subdirs[9]]
          num_frames = [num_files[2], num_files[4], num_files[6], num_files[8],
       →num_files[10]]
          num_frames = [num_frames for _, num_frames in sorted(zip(videos,_
       →num_frames))] # sorting based on videos list
          videos = sorted(videos)
          return frame_file_paths, videos, num_frames
[14]: def bar_plot(X, y, row_num = 1, col_num = 3, title = "Lidar Frames Per Video"):
          """Create a single bar plot with bar labels"""
          # Define plot dimensions and size
          rows = row_num
          cols = col_num
          plot_size = 4
          fig, ax = plt.subplots(rows, cols, figsize=(plot_size * cols, plot_size *_
       →rows), sharey=True)
          # Create subplot and loop through the seperate axes
          #fig, axes = plt.plot(rows, cols, figsize=(plot_size * cols, plot_size *_u
       →rows), sharey=True)
          y_limit = np.amax(X) # get max value in 2D array
```

```
ax.bar(y, X)
  ax.set_xticks(y) # Specify labels to suppress xticklabel warning
  ax.set_xticklabels(y, rotation=30)
  ax.set_title(title)
  ax.set_ylim([0, y_limit + 1000]) # increase y-axis to max value + 1000
  rects = ax.patches
  # Label bars with exact value
  labels = [f"label{i}" for i in range(len(rects))]
  for rect, label in zip(rects, X):
      height = rect.get_height()
      ax.text(
           rect.get_x() + rect.get_width() / 2, height + 5, label, ha="center", __

ya="bottom"


      )
  fig.text(0.5, -0.01, 'Video Number', ha='center')
  fig.text(-0.01, 0.5, 'Number of Frames', va='center', rotation='vertical')
  #fig.suptitle('Number of Frames Per Video')
  fig.tight_layout()
```

```
[15]: # File paths to each type of frame and number of frames
all_num_frames = []
lidar_frames = []

lidar_frames, video_number, num_frames = folder_info(LIDAR_DIR)
all_num_frames.append(num_frames)
```

## 2.1 Number of files per video

[16]: bar\_plot(all\_num\_frames[0], video\_number, row\_num=1, col\_num=1)



```
[17]: # Remove duplicates just in case - assuming they all have .ply extension
    print(len(lidar_frames))
    lidar_frames = list(set(lidar_frames))
    print(len(lidar_frames))
```

13555 13555

# Viewing lidar data in jupyter on the palmetto is too difficult so this will be continued in matlab

```
[18]: #import open3d as o3d #plt.set_loglevel('WARNING') # suppress warning caused by open3d
```

## Installing open3d on palmetto:

```
pip3 install --ignore-installed PyYAML
pip3 install open3d
```

```
[19]: #index = np.random.choice(len(lidar_frames))
#print(Path(lidar_frames[index]).stem)
#pcd = o3d.io.read_point_cloud(lidar_frames[index]) # Read the point cloud
#mesh = o3d.io.read_triangle_mesh("../../TestData/knot.ply")
#print(pcd)
#o3d.io.write_triangle_mesh("copy_of_knot.ply", mesh)
#o3d.visualization.draw_geometries([pcd])
```